



Installing MacBook Pro 15" Unibody Late 2008 and Early 2009 Access Door

Parts relevant to this guide

- [MacBook Pro 15" Unibody \(Late 2008/Early 2009\) Access Door](#)



Step 1 - Access Door

- With the case closed, place the Unibody top-side down on a flat surface.
- Depress the grooved side of the access door release latch enough to grab the free end. Lift the release latch until it is vertical.





Step 2

- The access door should now be raised enough to lift it up and out of the Unibody.